

METHOD #5 SINGLE VALVE

**NOTE: FOR BI-METAL VALVES ONLY
INCLUDING SINGLE TYPE TM SERIES**



HIGH TEMPERATURE FIXTURES (IF APPLICABLE)

NOTE:

SEE INSTALLATION INSTRUCTIONS FOR VALVE SPECIFIC PIPING DIAGRAMS AND SET UP PROCEDURE.

THERMOMETER ON VALVE MAY NEED TO BE REMOVED (AND PORT PLUGGED) AND RE-INSTALLED AFTER RETURN LINE TIE IN.

FOR MULTIPLE TEMPERED LOOPS A BALANCING VALVE AND CHECK VALVE MUST BE INSTALLED ON EACH LOOP AFTER TEMPERED FIXTURES.

