## **METHOD #5** TWO VALVE HIGH

**NOTE: FOR BI-METAL VALVES ONLY INCLUDING TYPE TM SERIES** 




LOW SYSTEM

NOTE: THIS PIPING METHOD IS USED FOR SYSTEMS WITH A CIRCULATED FLOW IN EXCESS OF EIGHT (8) GPM.

SEE INSTALLATION INSTRUCTIONS FOR VALVE SPECIFIC PIPING DIAGRAMS AND SET UP PROCEDURE.

THERMOMETER ON VALVE MAY NEED TO BE REMOVED (AND PORT PLUGGED) AND RE-INSTALLED AFTER RETURN LINE TIE IN.

FOR MULTIPLE TEMPERED LOOPS A BALANCING VALVE AND CHECK VALVE MUST BE INSTALLED ON EACH LOOP AFTER TEMPERED FIXTURES.



© 2015 Leonard Valve Company Printed in USA

1360 Elmwood Avenue, Cranston, RI 02910 USA Phone: 401.461.1200 Fax: 401.941.5310

Email: info@leonardvalve.com

Submittal S-M52 May 2015